


How to connect a USB printer to a laptop

1. Plug in the printer and ensure that it's turned off.

Set up the printer with ink and paper.

2. Connect a USB printer cable (shown below) to the printer and to your laptop.



3. Turn on the printer.

Because you're using a USB printer, it usually knows the printer's name and brand, and it even completely installs software for you, setting everything up and will prompt you that your device is ready to use.