

My laptop won't turn on!

How do I fix my Acer or Dell laptop if it won't Turn On?

ACER & DELL

1. Remove the AC adapter cable (Charger) from your laptop.
2. Press and hold the Power button for 30 seconds and release. ...
3. Plug the AC adapter cable (Charger) back into your laptop.
4. Press the Power button as normal to turn on your laptop.
5. It may take 15-30 seconds to display the green Acer or white Dell logo, but when it does you should be all set.